

# WIPE-RX® REFILLABLE NON WOVEN WIPES

## HOW TO USE



Only one quart of solution is needed for each WIPE-RX® roll. The fill level is marked on the outside of bucket.



You can use a dispensing system, measure device or use a gallon childproof cap from the Airx product to measure the chemical. Each cap is 1/8th of an ounce.



Add the proper amount of chemical to the bucket so you have a quart of solution ready for the WIPE-RX® roll.



Insert the roll of the WIPE-RX® into the bucket. It is better to allow the mixed chemical to migrate into the roll. It only takes 15-20 minutes for it to be absorbed.



As you put the cap on the bucket pull the roll of WIPE-RX® from the center and insert it through the pop up opening in the lid. Only leave enough to grab it.



Now you need to properly label the WIPE-RX® bucket. Choose one of the preprinted labels from the supplied packet and affix to the bucket.



Proper labeling is important to the WIPE-RX® program. You need correct handling instructions and cautions on each WIPE-RX® bucket. That is why we include them.

**AIRX LABORATORIES, 1640 DELMAR DRIVE, FOLCROFT, PA 19032-0037**

**PHONE (610) 534-8900 • FAX (610) 53408912 • Email- Sales@airxinfo.com • www.airxinfo.com**